

Lab 5 - Audio

Goals

- Interact with audio on the Microbit
- Play arbitrary tones using PWM
- Play analog waveforms using PWM

Equipment

- Computer with build environment
- Micro:bit and USB cable

Documentation

- nRF52833 datasheet: https://infocenter.nordicsemi.com/pdf/nRF52833_PS_v1.3.pdf
- Microbit schematic:
https://github.com/microbit-foundation/microbit-v2-hardware/blob/main/V2/MicroBit_V2.0_0_S_schematic.PDF
- Lecture slides are posted to the Canvas homepage

Lab 5 Checkoffs

You must be checked off by course staff to receive credit for this lab. This can be the instructor, TA, or PM during a Friday lab session or during office hours.

- **Part 2: Audio**
 - a. Demonstrate the `pwm_tone` code and application
 - b. Demonstrate the `record_and_play` code and application

Also, don't forget to answer the lab questions assignment on Canvas.

Lab Steps

Part 1: Setup

1. Find a partner

- Rule: you can pick any partner you want, but you can't pick the same partner twice
- You MUST work with a partner
 - We don't have enough computers otherwise

2. Set up your computer

- You can also use your personal computer if it's set up and you prefer
- Log into Windows
 - Password: 327-19s
- Open VMWare Workstation Player
- Open the virtual machine: CE346
 - It'll load for a minute and then ask you to log in
 - Password: microbit

3. Create your Github assignment repo

- Follow this link: <https://classroom.github.com/a/cPpNd6Tc>
- Pick a team name
- Pick your partner
- Generally, do what it says
- At the end, it should create a new private repo that you have access to for your code
 - Be sure to commit your code to this repo often during class!
 - If your computer crashes, all your files WILL BE LOST unless committed and pushed to Github.
- That link might 404. If it does, you first have to go to <https://github.com/nu-ce346-student> and join the organization

4. Create a personal access token

- If you still have your personal access token from prior weeks, you can skip this part
- Go to your github profile -> Settings
 - Then Developer Settings on the left
 - Then Personal Access Tokens on the left
 - Then click the Generate New Token button on the top right
- Add a note that is the name of this token (not important, type anything)
- **IMPORTANT:** check the repo checkbox below the name of the token
- Then scroll to the bottom of the screen and click the Generate Token button
- This will create a password that allows you to clone repos
 - It will only show this once, so copy-pasting it into a google doc in your personal drive would probably be useful
 - It will be in gray at the top of the screen

5. Clone your lab repo locally

- Open a terminal
- You can clone the repo right to the home directory of the computer
 - Remember, everything in this VM will disappear when it powers down
- At the top right of your shiny new private repo, there is a green button that says code. Copy the HTTPS link to your git repo from there.
- **IMPORTANT:** run this command and don't forget the flags
`git clone <YOUR-REPO-HTTPS-LINK-HERE> --recursive --shallow-submodules`
 - Remember to include both of those flags!
 - Recursive is necessary to clone submodules
 - Shallow submodules makes it like five minutes faster to run
 - If you forgot the flags, the command to fix this is:
`git submodule update --init --recursive --depth 1`

Part 2: Audio

1. Play tones over speaker with PWM

- cd into software/apps/pwm_tone/ You'll be editing main.c here
- Initialize the PWM peripheral

Use the `nrfx_pwm_init()` within the `pwm_init()` function

- [Documentation for the nrfx_pwm driver](#)
- You will need to make an `nrfx_pwm_config_t` local variable to pass into the initialize function
 - `output_pins` is an array of four GPIO pin numbers, use `SPEAKER_OUT` for the speaker pin and `NRF_PWM_PIN_NOT_USED` for unused pins
 - `base_clock` should be 500 kHz
 - `count_mode` should be Up
 - `top_value` is the default value for `COUNTERTOP` which we will overwrite later
 - `load_mode` should be Common
 - `step_mode` should be Auto
- We don't care about callback events for the PWM, so passing in `NULL` for the callback is fine
- Play a tone using the PWM peripheral

To do so, you'll need to fill in the code for `play_tone()` and call it from `main()`

- To stop the PWM, use `nrfx_pwm_stop()`
- Use `NRF_PWM0->COUNTERTOP` to access the `COUNTERTOP` register
- The PWM sequence variables have already been created for you globally. You will need to edit the value in order to set a 25% duty cycle
 - Note: you don't care if it's left or right alignment here, just set a value so that the toggle occurs at 25% of the way counting up to `COUNTERTOP`
 - 25% will make it audible but quiet. Going to 50% will make it louder.

- To start the PWM, use `nrfx_pwm_simple_playback()`
 - The instance is defined for you at the top of the file
 - You'll want to give it a flag so it plays the note indefinitely.
- Here is a list of [frequencies for the tones of a piano](#)
- Play multiple tones to form music
 - You can play whatever you want as long as it consists of at least four distinct notes, so feel free to play a short jingle or song
 - If you don't have any particular music in mind, the comments in main right now guide you through the A major arpeggio scale (A₄, C#₅, E₅, A₅), which is sufficient
 - You almost certainly want to stop the PWM after the last note so it doesn't continue playing it forever
- **Checkoff:** demonstrate your code and app to course staff
 - If it is too quiet to hear, you might have to bump duty cycle back up to 50% for the demonstration

2. Record audio and play it back over the speaker

- cd into software/apps/record_and_play/ You'll be editing main.c here
- The ADC side of the application has been provided for you

Look through the code already in the file. You shouldn't have to change any of this, but you'll definitely have to interface with it, so understanding what it is doing will be helpful.

- Initialize the PWM peripheral

Edit the function `pwm_init()` to do so

- This will be almost the same as the initialization from the previous part of the lab except that the PWM clock should be set to 16 MHz
- Also you will need to actually set a `COUNTERTOP` value here
- Play audio samples over the speaker using PWM

Edit `play_audio_samples_looped()` to do so

- First, modify each sample in place so it represents a PWM duty cycle rather than ADC counts. There is a `#define` for the maximum ADC value at the top of the file
 - Again, you don't have to worry about alignment here. Just set each value so that the toggle occurs at a duty cycle proportional to how large of an analog value you read
- Next, create the PWM sequence. You can copy some of this from the previous part of the lab.
 - You almost certainly want a non-zero repeat count. If repeat is zero, each analog sample is represented by exactly one PWM period. Instead, we want each sample to be represented by a few periods so that there is more than a single waveform to average energy across
 - Increasing the repeat count will require modifying `COUNTERTOP` however. Otherwise your playback will be at an incorrect frequency
 - Note that the value is the number of repetitions after the first play (so the total number of times a sample is played will be $1+\text{repeats}$)
- Finally, start the playback. You should loop the playback forever with the proper flag

- Test the record and play application

That should be everything needed to make the application work. You'll need to speak relatively loudly and pretty close to the Microbit in order for the output to be audible.

- If the output is loud and the correct speed, but distorted, you may be clipping the signal (it may have reached max). Try speaking a little softer
 - If the output is slow, you likely miscalculated the COUNTERTOP value, leading to the output playing at a slower frequency than it was recorded
 - You might want to make it so that pressing a button stops the PWM from playing so that it doesn't keep repeating you forever
- **Checkoff:** demonstrate your code and app to course staff