

Lab 5 - Audio

Goals

- Interact with audio on the Microbit
- Play arbitrary tones using PWM
- Play analog waveforms using PWM

Equipment

- Computer with build environment
- Micro:bit and USB cable

Documentation

- nRF52833 datasheet:
https://docs-be.nordicsemi.com/bundle/ps_nrf52833/attach/nRF52833_PS_v1.7.pdf
 - Online version: https://docs.nordicsemi.com/bundle/ps_nrf52833/page/keyfeatures_html5.html
- Microbit schematic:
https://github.com/microbit-foundation/microbit-v2-hardware/blob/main/V2/MicroBit_V2.0_0_S_schematic.PDF
- Lecture slides are posted to the Canvas homepage

Github classroom link: <https://classroom.github.com/a/JSgh9SsU>

Lab 5 Checkoffs

You must be checked off by course staff to receive credit for this lab. This can be the instructor, TA, or PM during a Friday lab session or during office hours.

- **Part 2: Audio**
 - a. Demonstrate the `pwm_square_tone` code and application
 - b. Demonstrate the `pwm_sine_tone` code and application
 - c. Demonstrate the `record_and_play` code and application

Also, don't forget to answer the lab questions assignment on Gradescope.

Lab Steps

Part 1: Setup

1. Find a partner

- Rule: you can pick any partner you want, but you can't pick the same partner twice
- You MUST work with a partner
 - If you can't find someone, talk to Branden

2. Create your Github assignment repo

- There is a github classroom link on the first page of this document. Click it!
- Pick a team name
- Pick your partner
- Generally, do what it says
- At the end, it should create a new private repo that you have access to for your code
 - Be sure to commit your code to this repo often during class!
- That link might 404. If it does, you first have to go to <https://github.com/nu-ce346-student> and join the organization
- **Important: both of you should join the repo before you can do the next step**

3. Set up an additional Git remote

- Open a terminal if you haven't yet
- `cd` into your "nu-microbit-base" repo
- At the top right of your shiny new private repo on the Github website, there is a green button that says "Code". If you set up an SSH key, you can click the SSH tab to get that URL, otherwise you should get the HTTPS URL. Either way, copy the URL so you can enter it into terminal
- `git remote add lab5 <YOUR-REPO-URL-HERE>`
 - This adds a "remote" repo hosted on github as a source for this repo
 - (Both of you should still do this step too)

4. Individual Setup Portions

- **ONLY ONE OF YOU** should do the following steps
 - `git fetch lab5`
 - This gets the most recent commits from the new remote source
 - `git checkout lab5/main`
 - This changes your current commit to the remote source's main branch
 - `git switch -c lab5-code`
 - This makes a new branch for your lab code
 - `git push -u lab5 lab5-code`
 - This tells the new branch to push code to the new remote source
 - From now on, you can just pull, commit, and push as normal
- **THE OTHER STUDENT** should do this **AFTER** the first student finished the above steps:
 - `git fetch lab5`
 - `git switch lab5-code`
- **BOTH STUDENTS** should do this
 - `git submodule update --init --recursive`
 - Makes sure all git submodules are initialized and updated

Part 2: Audio

Advance warning: more than any of the other labs, this lab is **conceptually** difficult, rather than a lot of code. In fact, you won't write that many lines for the entire lab, and there are only a few checkoffs. So, **what's really really important for this lab is attention to detail**. It's very easy to miss a step and have the whole system not work. So be careful with the instructions, and make sure you understand what's going on (and ask if you don't).

1. Play square wave tones over speaker with PWM

- cd into software/apps/pwm_square_tone/ You'll be editing main.c here
- Initialize the PWM peripheral

Use the `nrfx_pwm_init()` within the `pwm_init()` function

- [Documentation for the nrfx_pwm driver](#)
- You will need to make an `nrfx_pwm_config_t` local variable to pass into the initialize function
 - `output_pins` is an array of four GPIO pin numbers, use `SPEAKER_OUT` for the speaker pin and `NRF_X_PWM_PIN_NOT_USED` for unused pins
 - `base_clock` should be 500 kHz
 - `count_mode` should be Up
 - `top_value` is the default value for `COUNTERTOP` which we will overwrite later (pick anything for now)
 - `load_mode` should be Common
 - `step_mode` should be Auto
- We don't care about callback events for the PWM, so passing in `NULL` for the callback is fine
- Play a tone using the PWM peripheral

To do so, you'll need to fill in the code for `play_tone()` and call it from `main()`

- To stop the PWM, use `nrfx_pwm_stop()`
- Use `NRF_PWM0->COUNTERTOP` to access the `COUNTERTOP` register

- COUNTERTOP is the number of ticks in a PWM square wave cycle (ticks/cycle) so you'll pick a value based on the PWM input clock (ticks/second) and the desired output frequency (cycles/second)
 - The PWM sequence data array has already been created for you globally. You will need to edit the value in order to set a 25% duty cycle
 - Take a look at `sequence_data` at the top of the file
 - Note: you don't care if it's left or right alignment here, just set a value so that the toggle occurs at 25% of the way counting up to COUNTERTOP
 - 25% will make it audible but quiet. Going to 50% will make it louder.
 - To start the PWM, use `nrfx_pwm_simple_playback()`
 - The instance is defined for you at the top of the file
 - You'll want to give it a flag so it plays the note indefinitely.
 - Here is a list of [frequencies for the tones of a piano](#)
- Play multiple tones to form music
 - You can play whatever you want as long as it consists of at least four distinct notes, so feel free to play a short jingle or song
 - If you don't have any particular music in mind, the comments in main right now guide you through the A major arpeggio scale (A_4 , $C\#_5$, E_5 , A_5), which is sufficient
 - You almost certainly want to stop the PWM after the last note so it doesn't continue playing it forever
 - Note that `nrfx_pwm_simple_playback()` is non-blocking. It doesn't wait for the note to finish (the note will play forever anyways), it just sets it up and returns. So you might want to delay some time before changing the note.
- **Checkoff:** demonstrate your code and app to course staff
 - If it is too quiet to hear, you might have to bump duty cycle back up to 50% for the demonstration
 - *Question:* how did you determine COUNTERTOP, and what are the units of each part of that equation?

2. Play sine wave tones over speaker with PWM

Differently in this part (and part 3), we will now play samples from a buffer at a constant data rate. This more closely simulates how a DAC would work: there is some rate that analog samples are being produced at, with the analog value changing each time. We had to pick some sampling rate, and choose 16 kHz which is fast enough to handle *most* audible frequencies.

- cd into software/apps/pwm_sine_tone/ You'll be editing main.c here
- The sine wave computation has been provided for you

Look through the code already in the file. You shouldn't have to change any of this, but you will need to use the `sine_buffer` for creating your own output samples.

It takes about 50 μ s to calculate a single sine wave value. So for large buffer values, this can take a noticeable amount of a second to finish. We calculate the sine wave once at boot to make this more efficient, and then reuse the sine data to create the samples for our tones.

- Initialize the PWM peripheral

Edit the function `pwm_init()` to do so

- This will be almost the same as the initialization from the previous part of the lab except that the PWM clock should be set to 16 MHz
 - Also you will need to actually set a COUNTERTOP value here
 - In this example we have a constant frequency that we're playing PWM periods at, which is defined as the `SAMPLING_FREQUENCY`
 - For each data sample period, two PWM periods should play
 - We will later set the value of repeats so each PWM period is played twice
- Enable playing sine wave data over the speaker using PWM

Edit `play_note()` to do so

- To create each sample, you'll step cumulatively through the sine wave buffer and pull out the current sample value
 - Imagine a buffer of 10 samples of a sine wave for the entire sine period of 2π radians. If you want to go twice as fast as this, you step by twos and use every other sample.

- Here, we have 500 samples for a single sine wave period, and we need to step through them to create our own output samples based on the desired note frequency. The step value has been provided for you
 - Iterate through the `samples` buffer copying over values from `sine_buffer`
 - Make sure to wrap your cumulative steps back around if it would go past the `SINE_BUFFER_SIZE`.
 - Don't set it to zero though! It should be a type of modulus operation (except that you can't actually modulus floats)
 - Setting it to zero would be a discontinuity in the sine wave output, which will sound sort of like a click or wobble in the sound.
- Next, create the PWM sequence. You can copy some of this from the previous part of the lab.
 - You should set `repeats` to 1, for a total of two PWM periods per sample
 - Note that the value is the number of repetitions after the first play (so the total number of times a sample is played will be `1+repeats`)
- Finally, start the playback. You should loop the playback forever with the proper flag
- Pass in a maximum scale value to `compute_sine_wave()` in `main()`
 - The sine wave values range from 0 to `max_value`
 - Use `COUNTERTOP` as the maximum value to make your life simpler, as it means the sample data will already be portions of `COUNTERTOP`
- Play multiple tones to form music
 - The easiest choice here is to do whatever you did for the previous part of lab
 - **NOTE:** this is going to be very quiet. That's okay and expected!
 - You again almost certainly want to stop the PWM after the last note so it doesn't continue playing it forever

Checkoff: demonstrate your code and app to course staff

3. Record audio and play it back over the speaker

- cd into software/apps/record_and_play/ You'll be editing main.c here
- The ADC side of the application has been provided for you

Look through the code already in the file. You shouldn't have to change any of this, but you'll definitely have to interface with it, so understanding what it is doing will be helpful. Particularly note the sampling rate, as that will determine PWM timing.

- Initialize the PWM peripheral

Edit the function `pwm_init()` to do so

- This will be almost the same as the initialization from the previous part of the lab except that the PWM clock should be set to 16 MHz
- Also you will need to actually set a COUNTERTOP value here
 - For each data sample period, one or more PWM periods should play
 - This depends on the value of repeats you choose when setting up the PWM sequence
- Play audio samples over the speaker using PWM

Edit `play_audio_samples_looped()` to do so

- First, modify each sample in place so it represents a PWM duty cycle rather than ADC counts. There is a `#define` for the maximum ADC value at the top of the file
 - Again, you don't have to worry about alignment here. Just set each value so that the toggle occurs at a duty cycle proportional to how large of an analog value you read
- Next, create the PWM sequence. You can copy some of this from the previous part of the lab.
 - You almost certainly want a non-zero repeat count. If repeat is zero, each analog sample is represented by exactly one PWM period. Instead, we want each sample to be represented by a few periods so that there is more than a single waveform to average energy across
 - Increasing the repeat count will require modifying COUNTERTOP however. Otherwise your playback will be at an incorrect frequency. All repeated periods should happen within a single sample period.

- Note that the value is the number of repetitions after the first play (so the total number of times a sample is played will be 1+repeats)
 - Finally, start the playback. You should loop the playback forever with the proper flag
- Test the record and play application

That should be everything needed to make the application work. You'll need to speak relatively loudly and pretty close to the Microbit in order for the output to be audible.

- If the output is loud and the correct speed, but distorted, you may be clipping the signal (it may have reached max). Try speaking a little softer
 - If the output is slow, you likely miscalculated the COUNTERTOP value, leading to the output playing at a slower frequency than it was recorded
 - You might want to make it so that pressing a button stops the PWM from playing so that it doesn't keep repeating you forever
- **Checkoff:** demonstrate your code and app to course staff

If the instructors have a speaker setup on hand:

This app sounds WAY better if you use an external speaker. LIKE significantly better. Almost all of our problems are actually caused by the speaker on the Microbit.

- If we have an external speaker on hand for you to use, you can try out your application to see if it *really* works.
- You will need to make one change to code: have the PWM output to pin EDGE_P8.
 - You could even do this in addition to the existing SPEAKER_OUT rather than replacing it by adding it as a second output pin. That way your app works with OR without the external speaker.
- Connect your Microbit to the breadboard breakout (LED Matrix side up!!) to hear better audio quality.